

Instructions to Assemble the Projector for Movie Nights and Couple it to the Sounds System

1. Pull card table from under the stair case
2. Open the sound closet and take out
 - a. Projector
 - b. Cables
 - c. Cable adapters
 - d. Passive adapter box
 - e.
3. Get equipment from from youth group room
 - a. DVD Player
 - b. A/V Cable (Red/Yellow/White RCA cable)
 - c. extension cord
4. Plug ends of cables to snake use ports 5 & 6
5. Plug cable adapters into the passive direct box
6. Set projector with kickstand
7. Take cables from DVD and plug the yellow end to the yellow connector
8. Put the red and white plugs into the adapters connected to the passive direct box
9. Plug DVD Player into extension cord
10. Plug Projector into extension cord
11. Plug other end of extension cord to power source (outlet)
12. Turn on the amplifier switch on front
13. Turn on sound board in closet (power switch in back)
14. At the sound board Check that 5 & 6 are not muted, but turn down volume
15. Power up the DVD and Projector
16. Test system by putting movie in DVD player
 - a. Change source on projector if necessary
 - b. adjust display for
 - i. size
 - ii. keystone effect
 - c. adjust volume as necessary from sound board